

# Chrysler CDR 3.4 Coverage Jan. 2010

(North American Only listed)

Last 3 digits of Bosch CDR cable number shown			2005	2006	2007	2008	2009	2010
Chrysler	<b>300</b>	Center stack		228 <sup>3,5</sup>	228 <sup>5</sup>	228	228	228
Chrysler	<b>Aspen</b>	Console, aft			226 <sup>4</sup>	226	226	
Chrysler	<b>Pacifica</b>	Center stack			228 <sup>5</sup>	228 <sup>5</sup>		
Chrysler	<b>PT Cruiser</b>	Console, fwd			228 <sup>5,7</sup>	228 <sup>5</sup>	228	228
Chrysler	<b>Sebring</b>	Varies			226 <sup>4</sup>	226	226	516 <sup>8</sup>
Chrysler	<b>Town &amp; Country</b>	Center stack				385 <sup>6</sup>	385	
Dodge	<b>Avenger</b>	Varies				226	226	516 <sup>8</sup>
Dodge	<b>Caliber</b>	Varies			226 <sup>4</sup>	226	226	516 <sup>8</sup>
Dodge	<b>Caravan</b>	Center stack				385 <sup>6</sup>	385	
Dodge	<b>Challenger</b>	Center stack				228	228	228
Dodge	<b>Charger</b>	Center stack		228 <sup>3,5</sup>	228 <sup>5</sup>	228	228	228
Dodge	<b>Dakota</b>	Center stack			228 <sup>5</sup>	228	228	228
Dodge	<b>Durango</b>	Console, aft	226 <sup>2,4</sup>	226 <sup>2,4</sup>	226 <sup>2,4</sup>	226 <sup>2</sup>	226 <sup>2</sup>	
Dodge	<b>Journey</b>	Console, fwd					385	
Dodge	<b>Magnum</b>	Center stack		228 <sup>3,5</sup>	228 <sup>5</sup>	228		
Dodge	<b>Nitro</b>	Varies			227 <sup>4</sup>	227	227	516 <sup>8</sup>
Dodge	<b>Ram Cab Chassis</b>	Console, aft		226 <sup>4</sup>	226 <sup>4</sup>	226 <sup>4</sup>	226 <sup>4</sup>	453 <sup>8</sup>
Dodge	<b>Ram Pickup (25-5500)</b>	Console, aft of		226 <sup>4</sup>	226 <sup>4</sup>	226 <sup>4</sup>	226	453 <sup>8</sup>
Dodge	<b>Ram Pickup (1500)</b>	Varies		226 <sup>4</sup>	226 <sup>4</sup>	226	453 <sup>8</sup>	453 <sup>8</sup>
Jeep	<b>Commander</b>	Console, aft		228 <sup>3,5</sup>	228 <sup>5</sup>	228	228	228
Jeep	<b>Compass</b>	Center stack			226 <sup>4</sup>	226	226	516 <sup>8</sup>
Jeep	<b>Grand Cherokee</b>	Console, aft of		228 <sup>3,5</sup>	228 <sup>5</sup>	228	228	228
Jeep	<b>Liberty/Cherokee</b>	Varies				227	227	516 <sup>8</sup>
Jeep	<b>Patriot</b>	Center stack			226 <sup>4</sup>	226	226	516 <sup>8</sup>
Jeep	<b>Wrangler</b>	Console, aft of			227 <sup>4</sup>	227	227	

The source data for this chart is the Bosch CDR help file for Version 3.4 as of January 2010 & Chrysler  
 Always consult the latest help file for the most accurate coverage  
 Superscripts defined:

- 2 If equipped with side airbags (some without side bags might be read also)
- 3 Some 2006 models may contain EDR data not read by CDR tool
- 4 Records in **Frontal Deployments Only**
- 5 Wait 1 minute after powering up to read module
- 6 Some early 2008 modules may only read thru DLC
- 7 Some 2007 PT Cruisers may contain EDR data not read by CDR tool
- 8 Has capability to store Pre-crash data for Deploy and Nondeploy events
- 9 Blue = Records in deployments only

Copyright 2010  
 Ruth Consulting LLC  
 Authorized for use by IPTM

226 = 2 sec@0.1 no SAB, 5 sec w/SAB  
 227 = 5 sec @0.1 sec  
 228 = 5 sec @0.1 sec  
 385 = 5 sec @0.2 sec  
 453 = 5 sec@0.1 sec  
 516 = 5 sec@0.1 sec