

**GM Rollover Sensor Coverage Bosch CDR Version 3.4 (unchanged from 3.3)**  
**Green shading = will read ROS data IF VEHICLED IS EQUIPPED with ROS**

<u>Model</u>	<u>Module Location</u>	<u>2007</u>	<u>2008</u>	<u>2009</u>	<u>2010</u>
<b>BUICK</b>					
Enclave	Center Tunnel		455	455	In SDM
<b>CADILLAC</b>					
Escalade	Center Tunnel	455	455	455	In SDM
SRX	Center Tunnel	455	455	455	455
<b>CHEVROLET</b>					
Avalanche	Center Tunnel	455	455	455	In SDM
Captiva	Center Tunnel				455
Equinox	Center Tunnel	455	455	455	In SDM
Express			455	455	455
Silverado	Center Tunnel	455	455	455	In SDM
Suburban	Center Tunnel	455	455	455	In SDM
Tahoe	Center Tunnel	455	455	455	In SDM
Traverse	Center Tunnel			455	In SDM
<b>GMC</b>					
Acadia	Center Tunnel	455	455	455	In SDM
Savanna	Center Tunnel		455	455	455
Sierra	Center Tunnel	455	455	455	In SDM
Yukon	Center Tunnel	455	455	455	In SDM
<b>HUMMER</b>					
H2	Center Tunnel		455	455	455
<b>PONTIAC</b>					
Torrent	Center Tunnel	455	455	455	
<b>SATURN</b>					
Outlook	Center Tunnel	455	455	455	In SDM
Vue	Center Tunnel		455	455	455

Center Tunnel usually implies near the center of gravity between the front seats

455 is the last 3 digits of the Bosch CDr cable number for direct to module readouts

If vehicle is equipped with side curtains an "airbag" label will be on the B pillar

Vehicles not equipped will give a communication error when data retrieval is attempted via DLC

The source data for this chart is the Bosch CDR version 3.3 help file as of Aug 2008

Always consult the latest help file for the most accurate coverage.

Copyright Ruth Consulting LLC 2009 Authorized for use by IPTM